



CONCEALED HINGES WITH TWO CRANKED LEAVES - DRILLED - 120° OPENING - VERSION A

39-1-3886

Hinges for side door of baggage compartment (bus and coach, bodywork...) Use rivets for 4.2 diameter holes (door side). Use self-drilling screws for 12.2 diameter holes (frame side).





